

Bearing Housings

Housing selection, fit, alignment and maintenance guide

The housing, bearing insert, shaft and mounting structure must be treated as one assembly.

What this guide helps you do

Bearing housings support and locate bearing units and transfer loads into the machine structure. A housing choice affects shaft alignment, sealing, lubrication, mounting strength and maintenance access. The housing designation alone does not confirm that the installed bearing, shaft fit or operating conditions are suitable.

At a glance

Question	Why it matters
What is the application?	Defines load direction, duty cycle, environment and required life.
What is the complete arrangement?	Bearing, shaft, housing, seals, lubricant and mounting structure work together.
What must be confirmed before ordering?	Full designation, dimensions, load/speed conditions and approved technical data.

Document status: Technical reference guide · Revision 1.0 · October 2026

Prepared for engineering review and RFQ preparation. It is not a released product drawing, guaranteed rating, certificate or substitute for the selected manufacturer's catalogue.

Luoyang EIM Bearing Co., Ltd.
Website: www.eimbearing.com
Email: service@eimbearing.com
Tel: +86 379 6991 5786

1. Understand the bearing arrangement

Start by defining the function the bearing must perform. Similar-looking bearings can differ in load direction, stiffness, speed capability, mounting requirements and maintenance needs.

Application fit

- **Common arrangements:** Pillow blocks, flanged housings, take-up units and other configurations serve different mounting and adjustment needs. Confirm the actual type.
- **Complete assembly:** Check housing, insert bearing, locking method, seals, grease fittings, base and fasteners together.
- **Environment:** Dust, moisture, washdown, corrosion and temperature affect material, coating, seals and lubricant choice.

Design variants to compare

Configuration / feature	Selection notes
Pillow block	Base-mounted support; verify bolt spacing, base stiffness, shaft height and alignment access.
Flanged housing	Useful where the support mounts to a vertical or side face; verify bolt pattern, flange rigidity and shaft alignment.
Take-up or adjustable unit	Allows position adjustment in suitable applications; verify travel, locking and load direction.
Material and sealing	Cast iron, pressed steel, stainless or polymer-based options are not interchangeable in strength, corrosion and temperature behaviour.

Do not compare price or nominal size until the configuration, suffixes and interface dimensions are aligned. If a part is replacing an existing bearing, use the complete designation and drawing rather than appearance alone.

2. Selection inputs and interface checks

The table below is a working checklist. Record known values and mark unknown values for confirmation before quotation or engineering approval.

Input	What to provide / verify
Shaft	Diameter, tolerance, surface condition, material, straightness and required locking method.
Load and speed	Radial load, axial load, shock, speed, duty cycle and target life.
Mounting	Base/flange dimensions, bolt pattern, support stiffness, alignment and available space.
Bearing insert	Insert type, internal clearance, locking arrangement, seal design and relubrication feature.
Environment	Moisture, dust, chemicals, washdown, corrosion and operating temperature.
Maintenance	Grease access, replacement clearance, inspection interval and spare-part strategy.

Questions to resolve before approval

- Are loads steady, intermittent, reversing or shock-loaded?
- Is the stated speed continuous, peak, or a short-duration value?
- Are shaft and housing fits, shoulders and support stiffness known?
- Will temperature, lubricant or sealing requirements change during operation?
- Is interchangeability required, and what drawing or source confirms it?

When data are missing, state the assumption explicitly. Do not turn an unknown load, speed, clearance or preload into an invented numerical value.

3. Installation, lubrication and maintenance

Many early bearing failures are associated with contamination, poor fits, misalignment, inappropriate lubrication or installation damage. Follow the selected product’s installation instructions and document the final setting where relevant.

Installation checklist

- Confirm housing bore/seat and shaft size match the specified insert and locking method.
- Mount the housing on a clean, rigid, flat support. Avoid forcing a housing into alignment by tightening bolts unevenly.
- Align multiple housings before locking the shaft; misalignment can create unnecessary load and heat.
- Secure the shaft using the specified set screws, eccentric collar, adapter sleeve or other locking method for the exact unit.
- Apply the recommended lubricant, check seal orientation and verify that the shaft rotates freely after final tightening.

Symptom-to-check guide

Observed symptom	First checks
Insert bearing runs hot	Check shaft fit, misalignment, load, lubricant, seal friction and locking method.
Housing cracks or movement	Review load, base support, bolt sizing/preload, vibration and housing material.
Shaft slips	Verify shaft surface, locking method, tightening procedure and actual torque/load.
Contamination or water ingress	Inspect seals, shaft condition, washdown direction, grease purge and maintenance frequency.
Repeated misalignment	Check machine frame stiffness, shaft deflection, mounting datums and assembly sequence.

Record the operating condition when a symptom appears: load, speed, temperature, noise/vibration, lubrication state, recent maintenance and any change to the surrounding structure. This information helps separate a bearing issue from an installation or system issue.

4. RFQ checklist — send the right information

A complete RFQ reduces clarification cycles and helps the supplier check whether the requested bearing and arrangement match the application. Provide drawings or photos where dimensions and interfaces are difficult to describe.

- Housing type and full designation; insert bearing designation if known.
- Shaft diameter/tolerance, speed, load and duty cycle.
- Mounting drawing, bolt pattern, shaft height and available clearance.
- Locking method, seal type, relubrication feature and lubricant.
- Material/coating, corrosion exposure, temperature and washdown conditions.
- Required inspection, traceability, replacement strategy and spare parts.
- Quantity, packaging and delivery destination.

Suggested RFQ email structure

Field	Your information
Product / full designation	<div></div>
Quantity and annual demand	<div></div>
Application / equipment	<div></div>
Loads, speed and duty cycle	<div></div>
Dimensions / drawing number	<div></div>
Operating environment / lubricant	<div></div>
Quality documents / inspection	<div></div>
Delivery destination / target date	<div></div>

Need help confirming a designation or a substitution? Send the full model number, drawing, quantity and operating conditions to service@eimbearing.com or visit www.eimbearing.com.

5. Technical boundaries and final verification

This document provides general selection and procurement guidance. It does not provide product-specific rated loads, fatigue-life guarantees, maximum speeds, permissible misalignment, preload values, fit tolerances or installation torque unless those values are stated in an approved drawing or product-specific data sheet.

Before release to production

- Confirm the full bearing designation, suffixes and dimensional drawing.
- Confirm the source and revision of any load, speed, life or precision rating used in calculations.
- Verify the bearing, shaft, housing, seals, lubricant and mounting fasteners as a complete system.
- Record any deviations, substitutions and approval responsibilities.
- Follow the supplier's current installation, lubrication and maintenance instructions.

Important note

Catalogue values and suffix meanings may vary by manufacturer and product family. Where a guide describes a general bearing arrangement, it should not be interpreted as proof that two products are interchangeable. Confirm final technical suitability with the applicable product drawing and written supplier confirmation.

Contact EIM Bearing

Luoyang EIM Bearing Co., Ltd.
Website: www.eimbearing.com
Email: service@eimbearing.com
Tel: +86 379 6991 5786

End of guide · Revision 1.0 · October 2026